
Energy Software

Revenue Processing:
Asset Level Processes & Check Input

Energy Software



- Well and Meter Level Data loaded into Each Asset Via Excel Templates
- Physical Setup => Previously Allocated Volumes

- Cleans all processed data from later steps for the current accounting/production month
- Prevents results from double processing

- Levels Data with Gas Analysis
- Physical Results => Leveled Volumes

- Leveled and Balanced data will be allocated down to the well level via Allocation Setup (Basis Volume)
- Physical Results => Allocation Results

- Utilizes Allocation Results & Contracts/Rates to Associate Value at the Well Level
- Contractual Results => Valuation Results

- Use Valuation Results and Tax Groups to calculate the associated Tax Liability
- Taxes => Tax Results

- Combines Valuation and Tax Results and applies the necessary accounting components
- Accounting => Accounting Results

- Shows a preview of each owner before running company level processes
- Accounting => Preliminary Owner Amounts

- This process will prevent any further data loads or asset level processes to be run for the current accounting/production date
- This step is required for the asset level data to be picked up at the company level